

Special Instructions for your MOTOROLA RAZR V3



General Instructions

Powering On Your Phone

Press and hold <⓪> to turn your phone on and off. This key is also the <END> key and is located to the right of the **4-Way Navigation** key on your phone.

Answering Calls

To answer an incoming call, open the flip. Press <SEND> if necessary.

The <+> Sign

The <+> sign is obtained by pressing and holding the <0> until it appears on the display.

Inserting/Removing SIM from Handset



1. With the back of the phone facing you, press the release button and pull the cover off. Remove the battery.



2. Insert/remove the SIM.



3. Replace the battery and phone cover to the back of the phone.

Manually Select a Network

NOTE: Not all networks support data services, customers using data services may need to manually select a network that supports data. Visit www.sprint.com/international for information on data coverage, and a list of carriers which support data in the country you are traveling.

1. Press the **Menu** key
2. Select **Settings**
3. Select **Network**
4. Select **Available Networks**
5. Scroll to desired network
6. Select **View**
7. Select **Register**