

TIPS FOR USING BGAN

To ensure your BGAN terminal is working properly please follow these steps

1. Install LaunchPad software to your computer according to the User Guide
2. Connect the BGAN terminal to your computer via the LAN cable
3. Ensure there is an unobstructed view of sky
4. Acquire a **GPS fix**. Power “on” the terminal and lay flat until GPS “new” is displayed
5. Point the antenna based on the coordinates of the LaunchPad software
6. Register to the BGAN network using the LaunchPad software

To make a voice call:

1. Plug any regular analogue phone into the RJ-11 jack on the BGAN terminal
2. To make a call dial: **00 <country code> <phone number>** followed by **#**

***Example:** To call Roadpost in Mississauga (+1 905 272 5665) from an analogue phone dial: 00 1 905 272 5665 #*

IMPORTANT SAFETY INFORMATION

**Do not operate in an
explosive atmosphere!**

**Stay at least 0.6 meters away from
the front of the active antenna**



Do not touch!

**Areas of the terminal marked with
the symbol below get extremely hot.**



Support

+ 1 905 272 5665 or + 1 888 622 7368